

CONTENTS	
INTRODUCTION	INSTALLATION
1	3
STANDALONE MODE	CONTROLLER MODE
5	12
WIEGAND READER MODE	ADVANCED APPLICATION
14	15

INTRODUCTION
The device is a single door multifunction standalone access controller or a Wiegand output reader. It uses Atmel MCU assuring stable performance. The operation is very user-friendly, and low-power circuit makes it long service life.

The device supports 1,000 users (988 common users + 2 panic users + 10 visitor users), all user data can be transferred from one to another. It supports multi access modes in card access, PIN access, card + PIN access, or multi cards/PINs access. It has extra features including block enrollment, interlock, Wiegand input & output interface, etc.

Three Versions Optional:
The device with Bluetooth function is optional.
The device with big user capacity is optional.
The device with WIFI function is optional.

Features
> Touch key
> Metal case, anti-vandal
> Waterproof, conforms to IP66
> One relay, 1,000 users (988 common user + 2 panic + 10 visitor)
> PIN length: 4-6 digits
> EM card, EM+ Mifare cards optional
> EM card: Wiegand 26-44 bits input & output
> Mifare card: Wiegand 26-44 bits, 56bits, 58bits input & output
> Can be used as Wiegand reader with LED & buzzer output
> Card block enrollment
> Tricolor LED status display
> Integrated alarm & buzzer output
> Pulse mode, Toggle mode
> User data can be transferred
> 2 devices can be interlocked for 2 doors
> Built-in light dependent resistor (LDR) for anti tamper
> Backlit keypad, can set automatic OFF after 20 seconds

Specifications

User Capacity	1000
Common User	988
Panic User	2
Visitor User	10
Operating Voltage	12-18V DC
Working Current	≤150mA
Idle Current	≤60mA

-01-

Proximity Card Reader
EM / EM + Mifare
Radio Technology
Read Range
2-6 cm

Wiring Connections
Relay Output, Exit Button, Alarm, Door Contact, Wiegand Input, Wiegand Output

Relay
Adjustable Relay Output Time
Lock Output Level
2 Amp Maximum

Wiegand Interface
EM card: Wiegand 26-44 bits input & output.
Mifare card: Wiegand 26-44bits
56bits, 58bits input & output.
(Factory default: Wiegand 26bits for EM card, Wiegand 34bits for Mifare card)
4 bits, 8 bits(ASCII), 10 digits Virtual Number
(Factory Default: 4bits)

PIN Output

Environment
Operating Temperature
Operating Humidity
Meets IP66
-40°C ~ 60°C (-40°F ~ 140°F)
0%RH~98%RH

Physical
Color
Dimensions
Zinc-Alloy (A/B) ABS(C)
Silver & Black (A/B) Black(C)
1.148 x W43.5 x D22 (mm) → A/C
1.165 x W44 x D22 (mm) → B
330g → A 415g → B 190g → C
405g → A 500g → B 200g → C

Unit Weight
Shipping Weight

Carton Inventory

-02-

INSTALLATION
> Remove the back cover from the unit
> Drill 2 holes(A,C) on the wall for the screws and one hole for the cable supply
> Knock the supplied rubber bungs to the screw holes(A,C)
> Fix the back cover firmly on the wall with 4 flat head screws
> Thread the cable through the cable hole(B)
> Attach the unit to the back cover

Wiring

Wire Color	Function	Notes
Red	DC +	12-18V DC Power Input
Black	GNND	Negative Pole of DC Power Input
Blue & Black	Relay NO	Normally Open Relay Output (install diode provided)
White & Black	Relay Common	Common Connection for Relay Output
Green & Black	Relay NC	Normally Closed Relay Output (install diode provided)
Yellow	OPEN	Recovered to EXIT/RE-2 Input
Pass-Through Wiring (Wiegand Reader or Controller)		
Green	Data 0	Wiegand Output (Pass-through) Data 0
White	Data 1	Wiegand Output (Pass-through) Data 1

Advanced Input and Output Features

Grey	Alarm Output	Negative contact for Alarm
Brown	Contact Input	Door/Gate Contact Input (Normally Closed)
Brown & Black	Doorbell A	Contact for Doorbell
Yellow & Black	Doorbell B	Contact for Doorbell

-03-

Sound and Light Indication

Operation Status	LED	Buzzer
Stand by	Red light bright	—
Enter into programming mode	Red light shines	One beep
In the programming mode	Orange light bright	One beep
Operation error	—	Three beeps
Exit from the Programming mode	Red light bright	One beep
Open lock	Green light bright	One beep
Alarm	Red light Shines quickly	Beeps

Basic Configure

Enter and Exit Program Mode

Programming Step	Keystroke Combination
Enter Program Mode	* (Master Code) #
Exit Program Mode	* (Factory default is 123456)

Set Master Code

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Update Master Code	0 (New Master Code) # (Repeat New Master Code) # (Master code is any 6 digits)
3. Exit Program Mode	*

Set the Working Mode
Notes: The device has 3 working modes: Standalone Mode, Controller Mode, Wiegand Reader Mode, choose the mode you use, (Factory default is Standalone Mode / Controller Mode)

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Standalone/Controller Mode	7 7 # (Factory default)
OR	
2. Wiegand Reader Mode	7 8 #
3. Exit	*

-04-

STANDALONE MODE
The device can work as Standalone Access Control for single door. (Factory default mode) → 7 7 #

Common Power Supply

Access Control Power Supply

Attention: Install a 1N4004 or equivalent diode is needed when use a common power supply, or the keypad might be damaged. (1N4004 is included in the packing)

-05-

Programming
will be varied depending on access configuration. Follow the instructions according to your access configuration.

Notes:
> **User ID Number:** Assign a user ID to the access card/ PIN in order to track it.
The Common User ID: 0-987
Panic User ID: 988 - 989
Visitor User ID: 990 - 999

IMPORTANT: User IDs do not have to be proceeded with any leading zeros. Recording of User ID is critical. Modifications to the user require the User ID be available.

> **Proximity Card:**
Factory default: EM card/ EM+ Mifare cards
> **PIN:** Can be any 4-6 digits except 8888 which is reserved.

Add Panic Users
PIN Card user ID: 0-987; PIN length: 4-6 digits except 8888

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
Add Card User	1 (Read Card) / (Input 8/10/17 Digits Master Code) #
2. Using Auto ID (Allow the device to assign Card to next available User ID number)	1 (Read Card) / (Input 8/10/17 Digits Master Code) #
OR	
2. Select Specific ID (Allows Master to define a specific User ID to associate the PINs)	1 (User ID) / (Read Card / Input 8/10/17 Digits Card Number) #
OR	
2. Add Card: Block Enrollment (Allows Master to add up to 988 Cards to the Reader in a single step) Takes 2 minutes to program.	1 (User ID) / (Card Quantity) # (The First Card 8/10/17 Digits Number) # (Card number must be consecutive, Card quantity=numbers of cards to be enrolled)
3. Exit	*

-06-

Add PIN User
2. Using Auto ID (Allow the device to assign PIN to next available User ID number)
OR
2. Select Specific ID (Allows manager to define a specific User ID to associate the PINs)
3. Exit

1 (PIN) #
The PINs can be added continuously

1 (User ID) # (PIN) #

*** (Master Code) #**

Tips for PIN Security (Only valid for 6 digits PIN):
For higher security we allow you to hide your correct PIN with other numbers up to a max of 10 digits.
Example PIN: 123434
You could use *123434* or *1123434*
(*) can be any numbers from 0-9)

Add Panic Users
(User ID number is 988, 989; PIN length: 4-6 digits except 8888)

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
Add Card User	1 (User ID) # (Read Card / Input 8/10/17 Digits Card number) #
OR	
2. Add Card	1 (User ID) # (Read Card / Input 8/10/17 Digits Card number) #
OR	
2. Add PIN	1 (User ID) # (PIN) #
3. Exit	*

Add Visitor Users
(User ID number is 990-999; PIN length: 4-6 digits except 8888)
There are 10 groups Visitor PIN/card available, the users can be specified up to 10 times of usage, after a certain number of times, i.e. 5 times, the PIN/card become invalid automatically.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Delete User - By Card number	2 (User ID) #
OR	
2. Delete User - By Card number	2 (input 8/10/17 Digits Card Number) #
OR	
2. Delete ALL Users	2 (Master Code) #
3. Exit	*

-07-

Change PIN Users
(PIN length: 4-6 digits except 8888)
(Note: WIFI versions don't support change PIN)

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Add Card	1 (User ID) # (Read Card / Input 8/10/17 Digits Card number) #
OR	
2. Add PIN	1 (User ID) # (PIN) #
3. Exit	*

Delete Users

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Delete User - By ID number	2 (User ID) #
OR	
2. Delete User - By Card number	2 (input 8/10/17 Digits Card Number) #
OR	
2. Delete ALL Users	2 (Master Code) #
3. Exit	*

-08-

Set Relay Configuration
The relay configuration sets the behavior of the output relay on activation.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Pulse Mode	3 (1-99) # (factory default)
OR	
2. Toggle Mode	3 # (factory default)
3. Exit	*

Set Access Mode
For Multi user access mode, the interval time of reading can not exceed 5 seconds, or else, the device will exit to standby automatically.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Card Access	4 0 #
OR	
2. PIN Access	4 1 #
OR	
2. Card + PIN Access	4 2 # (WIFI versions don't support this function)
OR	
2. Card or PIN Access	4 3 # (factory default)
OR	
2. Multi User Access	4 3 (2-9) # (Only after 2-9 valid users, the door can be opened)
3. Exit	*

Set Strike-out Alarm
The strike-out alarm will engage after 10 failed entry attempts (Factory is OFF). It can be set to deny access for 10 minutes after engaging or disengage only after entering a valid card/PIN or Master code / card.

-09-

Simplified Instruction

Function Description	Operation
Enter the Programming Mode	* (Master Code) #
Change the Master Code	0 - New Code - # - Repeat the New Code - # (code: 6 digits)
Add Card User	1 - Read Card - # (can add cards continuously)
Add PIN User	1 - PIN - # (The PIN is any 4-6 digits except 8888 which is reserved)
Delete User	2 - Read Card - #
	2 - PIN - #
Exit from the Programming Mode	*
How to release the door	
Card User	Read Card
PIN User	Input PIN #

-10-

Programming Step

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Strike-Out OFF	6 0 # (factory default)
OR	
2. Strike-Out ON	6 1 # Access will be denied for 10 minutes (Exit button is still workable)
OR	
2. Strike-Out ON (Alarm)	6 2 #
2. Strike-Out ON (Alarm)	5 (0-3) # (factory default is 1 minute)
3. Exit	*

Set Door Open Detection
Door Open Too Long (DOTL) Detection
When use with an optional magnetic contact or built-in magnetic contact of the lock, if the door is opened normally, but not closed after 1 minute, the inside buzzer will beep automatically to remind people to close the door. The beep can be stopped by closing the door, master users or valid users, or else, it will continue to keep the same time with the alarm time set.

Door Forced Open Detection
When use with an optional magnetic contact or built-in magnetic contact of the lock, if the door is opened by force, the inside buzzer and external alarm (if there is) will both operate, they can be stopped by master users or valid users, or else, it will continue to sound the same time with the alarm time set.

Programming Step

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Disable Door Open Detection	6 3 # (factory default)
OR	
2. Enable Door Open Detection	6 4 #
2. Set Alarm Time	5 (0-3) # (factory default is 1 minute)
3. Exit	*

The function of Set Alarm Time also apply for anti-tamper alarm

-11-

Set Audible and Visual Response

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Disable Sound	7 0 #
Enable Sound	7 1 # (factory default)
OR	
2. LED Always OFF	7 2 #
LED Always ON	7 3 # (factory default)
OR	
2. Keypad Backlit Always OFF	7 4 #
Keypad Backlit Always ON	7 5 #
Keypad Backlit Always ON	7 6 # (factory default)
Automatic OFF after 20 seconds, it will go ON by pressing any key (this key will not taken into consideration)	
3. Exit	*

Master Card Usage
Using Master Card to add and delete users

Add Card/PIN Users

Programming Step	Keystroke Combination
1. Input (Master Card Twice with (C)S)	1. Input (Master Card) #
2. Input (Card) or (PIN) #	2. Input (Card) or (PIN) #
3. Input (Master Card) again	3. Input (Master Card) #

Delete Card/PIN Users

Programming Step	Keystroke Combination
1. Input (Master Card Twice with (C)S)	1. Input (Master Card) #
2. Input (Card) or (PIN) #	2. Input (Card) or (PIN) #
3. Input (Master Card) again	3. Input (Master Card) #

Users Operation & Reset to Factory Default
> Open the door: Read valid user card or input valid user PIN #
> Remove Alarm: Enter Master Code or Master Card or valid user card / PIN

-12-

> To reset to factory default & Add Master Card: Power off, press the Exit Button, hold it and power on, there will be two beeps, then release the exit button, the LED light turns into yellow, then read any 12kHz EM card/ 13.56MHz Mifare card, the LED will turn into red, means reset to factory default successfully. Of the card reading, it is the Master Card.

Remarks:
① If no Master Card added, must press the Exit Button for at least 5 seconds before release, (this will make the previous registered Master Card invalid)
② Reset to factory default, the user's information is still retained.

CONTROLLER MODE
The device can work as Controller, connected with the external Wiegand reader. (Factory default mode) → 7 7 #

Connection Diagram

Attention: Install a 1N4004 or equivalent diode is needed when use a common power supply, or the reader might be damaged. (1N4004 is included in the packing)

-13-

Set Wiegand Input Formats
Please set the Wiegand input formats according to the Wiegand output format of the external Reader.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Wiegand Input Bit	8 (or 4 or 8 or 10) # (factory default is 4 bits)
3. Exit	*

Remarks: 4 means 4 bits, 8 means 8 bits, 10 means 10 digits virtual number.

> **Add PIN Users:**
To add PIN users, after enter into programming mode on the device, PINs can be input / added on either the device or the external Keypad Reader.

> **Delete PIN Users:** the same way as add users.

WIEGAND READER MODE
The device can work as Standard Wiegand Reader, connected to the third party Controller → 7 8 #

Connection Diagram

Notes:
> When set into Wiegand Reader mode, nearly all settings in Controller Mode will become invalid, and Brown & Yellow wires will be redefined as below:
- Brown wire: Green LED light control
- Yellow wire: Buzzer control
> You need to connect Brown/Yellow wires: When the input voltage for LED is low, the LED will turn into Green; and when the input voltage for Buzzer is low, it will sound.

-14-

The device Connected with Keypad Reader
The keypad reader can be 4 bits, 8 bits (ASCII), or 10 Bits output format. Choose the below operation according to the PIN output format of your reader.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. PIN input bits	8 (4 or 8 or 10) # (factory default is 4 bits)
3. Exit	*

Remarks: 4 means 4 bits, 8 means 8 bits, 10 means 10 digits virtual number.

> **Add PIN Users:**
To add PIN users, after enter into programming mode on the device, PINs can be input / added on either the device or the external Keypad Reader.

> **Delete PIN Users:** the same way as add users.

WIEGAND READER MODE
The device can work as Standard Wiegand Reader, connected to the third party Controller → 7 8 #

Connection Diagram

Notes:
> When set into Wiegand Reader mode, nearly all settings in Controller Mode will become invalid, and Brown & Yellow wires will be redefined as below:
- Brown wire: Green LED light control
- Yellow wire: Buzzer control
> You need to connect Brown/Yellow wires: When the input voltage for LED is low, the LED will turn into Green; and when the input voltage for Buzzer is low, it will sound.

-15-

Set Wiegand Output Formats
Please set the Wiegand output formats of Reader according to the Wiegand input formats of the Controller.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Wiegand output bits	8 (factory default is 26bits) For EM Card: 8 (26-44, 56, 58) # (factory default is 34bits) 8 (4 or 8 or 10) # (factory default is 4 bits)
3. Disable Parity Bit	8 0 #
Enable Parity Bit	8 1 # (factory default)
4. Exit	*

Notes: For connecting Wiegand controller with 32, 40, 56 bits input, need disable parity bits.

ADVANCED APPLICATION
Collection Card Mode
After this mode is turned on, all cards can open the lock. At the same time, the card is added to the device.

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Collection Card Mode OFF	9 2 # (factory default)
OR	
2. Collection Card Mode ON	9 3 #
3. Exit	*

User Information Transfer
The device supports the User Information Transfer function, and the enrolled user (cards, PINs) can be transferred from one (let's name it Master Unit) to another (let's name it Accept Unit).

Notes:
> For full 1000 users enrolled, the transfer takes about 30 seconds.

Set Transferring on Master Unit:

Programming Step	Keystroke Combination
1. Enter the programming mode	* (Master Code) #
2. Set transferring	9 5 #
3. Exit	*

-16-

Connection Diagram:

Remarks:
> The Master units and Accept units must be same series devices.
> The Master Code of the Master Unit and the Accept Unit must be set to the same.
> Program the transfer operation on Master Unit only.
> If the Accept Unit is already with the users enrolled, it will be covered after transferring.
> For full 1000 users enrolled, the transfer takes about 30 seconds.

Set Transferring on Master Unit:

Programming Step	Keystroke Combination
1. Enter the programming mode	* (Master Code) #
2. Set transferring	9 5 #
3. Exit	*

User Information Transfer
The device supports the User Information Transfer function, and the enrolled user (cards, PINs) can be transferred from one (let's name it Master Unit) to another (let's name it Accept Unit).

Notes:
> For full 1000 users enrolled, the transfer takes about 30 seconds.

-17-

Interlock
The device supports the Interlock Function. It is of two Devices for two doors, and mainly used for banks, prisons, and other places where a higher level security is required.

Connection Diagram:

Remarks: The Door Contact must be installed and connected as the diagram.

Let's name the two Devices as "A" and "B" for two doors "1" and "2"

Step 1:
Enroll the users on Device A, then transfer the users' information to Device B by "User Information Transfer" function.

Step 2:
Set both of the two Devices (A and B) to Interlock function

Programming Step	Keystroke Combination
1. Enter Program Mode	* (Master Code) #
2. Disable Interlock	9 0 # (factory default)
OR	
2. Enable Interlock	9 1 #
3. Exit	*

If enable interlock, when and only door 2 is closed, the user can read the valid fingerprint/card or input PIN on Reader A, door 1 will open; then when and only door 1 closed, read valid fingerprint/card or input PIN on Reader B, door 2 will open.

-18-

Access Controller / Reader (With Doorbell)

User Manual

-19-