

P ▲ R ▲ G D O X™  
**TM50 In-Wall Bracket  
Installation Manual**

## Instructions

1. Select location for the TM50 and cut out drywall using the back cover of the in-wall bracket as a guide.
2. Insert back cover of the in-wall bracket, make sure the arrow is pointing in the UP position.
3. Screw the drywall anchors until they flush to the wall; do not over-tighten.
4. Secure TM50 backplate into the in-wall bracket.
5. Mount the TM50 into its backplate.
6. Clip TM50 in-wall bracket cover to the TM50 in-wall bracket.

