

I N S T E O N[®]




INSTEON LED Bulb (PAR38)

2674-422, 2674-522

Quick Start Guide

INSTEON LED Bulb (PAR38)




|
INSTEON ID



For the complete Owner's Manual and more, visit: insteon.com/support


Do Not Connect to a Dimmer

LED Bulb dims using INSTEON commands.



Leave Your Fixture On

If your switch or fixture is OFF, communication with the LED Bulb is lost. See the Owner's Manual for steps to wire your fixture as always-on.




Linking

Your LED Bulb does not have a set button. To link manually, unscrew the LED Bulb for a moment and reinsert.




Linking to the Hub

- 1 Follow the on-screen instructions to add the LED Bulb to your INSTEON Hub.



2


Turn your fixture on and when prompted, screw in the LED Bulb.



Linking complete. You can now control your LED Bulb from the App.

Device Control

Dim, brighten, set schedules and create scenes for your LED Bulb using the INSTEON Hub and App.



Create a Schedule

To turn your LED Bulb on and off automatically with sunrise, sunset or any arbitrary time, tap Schedules from the LED Bulb settings.

