

## RJ/PIN5

RS-232 CABLE

RJ/PIN5 is a cable for connecting RS ports of **INTEGRA** control panels provided with RJ socket with communication modules having PIN–5 connector, i.e. GSM, ISDN–MOD, ETHM–1, ETHM–1 Plus, as well as MDM56 BO modem.

 cable for connection of RS Ports of INTEGRA panels equipped with RJ connector and modules equipped with PIN-5 connector (MDM56 BO modems, GSM, ISDN–MOD , ETHM–1, ETHM–1 Plus modules)

