



BINOCULAR TRIPOD ADAPTER



Included:

- | | |
|----------------|------------------|
| a. Lock Washer | d. Receiver Base |
| b. Post | e. Hex Wrench |
| c. Screw | |



Instructions:

1. Remove cap covering the binocular tripod adapter socket.
2. Insert lock washer into cut space on post. Then, install screw.
3. Using the hex wrench, tighten the post portion to binocular. **Do not overtighten.**
4. Attach adapter to tripod:



- **With Base:** Connect receiver base to tripod and place post into receiver



Note: Be sure to remove the binocular from the receiver base before moving the tripod. (The binocular is not fastened to the receiver base.)

- **Without Base:** Connect the post portion directly to the tripod.