


## Package Contents



Router × 1



Power Adapter × 1



Ethernet Cable × 1




Quick Start Guide × 1

## Connect the Device

- Power off the modem, and remove the backup battery if it uses.
- Make sure that the router is close to a power outlet and near Ethernet cables for wired computers.
- Place the router horizontally and orient the antennas vertically.

**i** Images may differ from the actual product.



## LED and Buttons

### LED Patterns

- Flashing green WPS mode
- Solid green Internet connected
- Solid red No Internet connectivity
- Green & Red Updating firmware
- Off Device is powered off/LED is turned off

### Reset Button

Press and hold the button for more than 5s to reset the router to its factory mode.


### WPS Button

Press the button for 1s to start the WPS process.

## Set Up the Network

### Method 1: Via a Web Browser

1. Connect to the network name (SSID) displayed on the device label on the router.  
For security, change to a unique SSID and assign a password.



2. Launch a web browser. Key in <http://imouwifi.net> in the address bar.



3. Follow the on-screen instructions to set up the Internet connection.

### Method 2: Via the Imou Life App

1. Download the Imou Life App.



OR



Scan to get Imou Life App

2. Open the Imou Life App and log in.  
**i** If you are a new user, please register an account first.
3. Add your devices. Follow the instructions on the app to complete the setup and connect to the internet.



## FAQ

### Q1: What should I do if I can't access the router's management page?

- Reboot your router and try again.
- Check your Wi-Fi connection.
- Use another Web browser such as Google Chrome.
- Restart your device.

### Q2: What should I do if I can't access Internet?

- Reboot your modem and router, then try again.
- Check the Internet is working. With an Ethernet cable connecting the modem to the computer directly.

### Q3: What should I do if I forget my Web management page password?

- Check the Web password on the label at the bottom of the router.
- When the router is power on, use a pin to press and hold the RESET button on the back until the LED blinks. Then the password will restore to the default that marked on the label.

### Q4: What can I do if my Wi-Fi devices cannot connect over Wi-Fi to the router?

Please try to check:

- You have enabled the router's SSID network broadcast and displays in your Wi-Fi client's scanning list.
- You have entered the correct Wi-Fi password when connecting your devices to the Wi-Fi network.

If you failed to address the problem, you can reset the router to factory default settings.



# Dual-band Wi-Fi Router Quick Start Guide

V1.0.0

---

 For the user guide, support, and more information, please visit <https://www.imoulife.com/support>

 Email [service.global@imoulife.com](mailto:service.global@imoulife.com) to give suggestions.

 Follow [@imouglobal](https://www.facebook.com/imouglobal) to get more brand information.