### ©2023 Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.

### About this Manual

- . The Manual includes instructions for using and managing the Product, Pictures, charts, images and all other information hereinafter are for description and explanation only. The information contained in the Manual is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of this Manual at the Hikvision website (https://www.hikvision.com/).
- Please use this Manual with the guidance and assistance of professionals trained in supporting the Product.

### Trademarks

- . HIKVISION and other Hikvision's trademarks and logos are the properties of Hikvision in
- various jurisdictions. Other trademarks and logos mentioned are the properties of their respective owners.

HIKVISION

8-Port 100 Mbps Ethernet Switch

Ouick Start Guide

- Disclaimer TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW. THIS MANUAL AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED
- "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED. INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY OLIALITY. OR FITNESS FOR A PARTICULAR PURPOSE, THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL CONSEQUENTIAL INCIDENTAL OR INDIRECT DAMAGES, INCLUDING AMONG OTHER DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.
- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK. HACKER ATTACK VIRUS INFECTION OR OTHER INTERNET SECURITY RISKS: HOWEVER HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE. FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES. INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS, YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES. INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION. THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR
- UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES. . IN THE EVENT OF ANY CONFLICTS BETWEEN THIS MANUAL AND THE APPLICABLE LAW. THE LATTER PREVAILS.

### Applicable Models

This manual is applicable to 8-Port 100 Mbps Ethernet Switch.

### Symbol Conventions

The symbols that may be found in this document are defined as follows.

Symbol	Description	
	Provides additional information to emphasize or suppleme important points of the main text.	
/!\ caution	Indicates a potentially hazardous situation, which if not avoided could result in equipment damage, data loss, performance degradation, or unexpected results.	
	Indicates a hazard with a high level of risk, which if not avoided	

# 1 Note

- . During the installation and utilization of the device, please strictly conform to electrical safety rules in different nations and regions.
- This is a class A product and may cause radio interference in which case the user may be required to take adequate measures.
- Ensure to use the attached power adaptor only and not to change the adaptor randomly. Please refer to specification table for specific requirements of power adaptor.
- . If the product does not work properly, please contact your dealer or the nearest service
- . Never attempt to disassemble the device yourself. (We shall not assume any responsibility for problems caused by unauthorized repair or maintenance.)

# Caution

during shipping.

- . The device must be installed in machine room only, and only maintenance staff or qualified person should access the device.
- . Do not touch the upper cover area of the device that may be overheated.
- . Power must be shut down during cable connection, device installation and
- dismantlement. . You shall acknowledge that the use of the device with Internet access might be under network security risks, please strengthen protection for your personal information and data security. If you find the device might be under network security risks, please contact
- Proper configuration of all passwords and other security settings is the responsibility of
- the installer, and you shall keep user name and passwords properly. . Please keep all original packing materials properly. If the product does not work properly, pack the switch in its original packing materials for shipping. We shall not assume any responsibility for damages caused by improper packing materials

# Packing List








Power Adapter × 1

Ouick Start Guide x 1

 Multilingual Information of Network Switch x 1

## Appearance



No.	Indicator/Port	Description
1	100 Mbps RJ45 Port	Used for connection to another device via a network cable.
2	LINK/ACT Indicator	Indicates the statuses of 100 Mbps RJ45 ports 1 to 8.
3	PWR Indicator	Indicates the power status of the switch.
4	Power Supply	Use the attached power adapter to connect the switch to a socket.

### Device Installation

Please select the appropriate installation method according to the actual needs.

nstallation Method	Steps	
Desktop Installation	Place the device on the desk.	
	Check the distance between the two hanging holes on the rear panel of the device.	
Wall-Mounted Installation	2. Insert two M4 screws into the wall.	
	Align the hanging holes with the screws, and hang the device on the screws.	

## i Note

- Prepare screws yourself.
- Ensure that the distance between the two screws equals to the distance between the two hanging holes.
- Set aside at least 4 mm of the screw bodies outside the wall.

## Power-On Check

See the following table and check whether your devices are correctly connected. After proper connection, you can use your switch without doing any settings.



Please use the power adapter attached in the package to supply power to the switch.


	Indicator	Status	Description
	PWR	Solid on	The switch is powered on normally.
		Unlit	No power supply connected or power supply is abnormal.
	LINK/ACT	Solid on	The port is connected.
		Flashing	The port is transmitting data.
		Unlit	The port is disconnected or connection is abnormal.



The switch supports auto MDI/MDIX of ports, you can use straight-through cables or crossover cables to connect the switch and opposite Ethernet devices.

## **Device Connection**

Connect your devices according to your actual networking requirements.



UD33403B

