


Package contents

- Mesh5 x 2
- 12 V 1 A power adapter x 2
- Ethernet cable x 1
- Quick installation guide x 1

*MW5c is a serial name coming with one, two or three Mesh5.

Get to know your device



Reset button
DC power jack
10/100/1000 Mbps WAN/LAN port
10/100/1000 Mbps LAN port
Mesh5

I Install the Tenda WiFi App

Download the **Tenda WiFi** App onto your mobile device by searching for **Tenda WiFi** in the App Store/Google Play, or by scanning the QR code. Then, install the App.



Available for iOS and Android

Or




Tenda WiFi

II Connect the primary node


* The first node you set up functions as the primary node, while the rest is referred to as the secondary node.

- Power off your modem, and remove its battery (if any).
- Use the included Ethernet cable to connect a LAN port of your modem or the Ethernet jack to the **WAN/LAN** port of the any node. This node is your primary node.
- Reinstall the battery of your modem, and power it on.
- Use the included power adapter to connect the primary node to a power source, and its LED indicator lights solid green. Wait for about 40 seconds. The system completes startup when the LED indicator blinks green.



III Connect your mobile device to the primary node

Go to the WiFi network list on your mobile device, select the SSID of the primary node, and enter its password. The default SSID and password are specified on the bottom label of any node.



IV Set up the primary node for internet access


Run the **Tenda WiFi** App and follow the onscreen instructions to set up the primary node for internet access. After the primary node is connected to the internet, its LED indicator should turn a solid green.



LED indicator

V Connect the secondary node to the internet

- For the best performance, place the secondary node:
 - In an elevated, open position within coverage area of your existing nova WiFi network.
 - Keep the node away from electrical equipment with strong interference, such as microwave ovens, induction cookers and refrigerators.
- Use the other power adapter to connect the secondary node to a power source, its LED indicator lights solid green. Wait for about 40 seconds. The secondary node is connecting to the primary node when its LED indicator blinks green.



3. When the secondary node is connected, its LED indicator shows as follows:

Solid green	Good connection
Solid yellow	Fair connection
Solid red	Disconnected

4. If the LED indicator of the secondary node does not light solid green, relocate it according to step 1 in **V** to get a better connection.

Done.

- To access the internet with:
 - Wired devices: Connect wired devices to the LAN ports of your nodes.
 - Wireless devices: Connect wireless devices to your WiFi network using the SSID and password you set.
- If you want to manage the network anytime, anywhere, access the App, tap and log in to your account.

LED indicator description

After a node is powered on, the LED indicator lights solid green for about 40 seconds to complete startup. Then, the LED indicator lights one of the following colors:

Node Type	Status	Description
The primary node	Blinking green	Connecting to the internet.
	Solid green	Connected to the internet.
The secondary node	Solid red	Disconnected.
	Blinking green fast	Connecting to a node.
	Blinking green slowly	Wait for connecting to another node, or searching for another node.
	Solid green	Good connection.
	Solid yellow	Fair connection.
	Solid red	Disconnected.

FAQ

Q1: How can I change my SSID and password?

A1: Run the **Tenda WiFi** App, tap **Settings** in the lower-right hand corner, tap **Wireless Settings**, change your SSID and password, and tap **Save**.

After changing your SSID and password, you need to reconnect your mobile devices using the new SSID and password.

Q2: How can I remove a node from my WiFi network?

A2: Tap the node on the **Tenda WiFi** App, tap "... " in the upper-right corner, and choose **Delete**.

Note: This removing operation restores the node to factory settings.

Q3: Can I add another new set of node to expand my network coverage?

A3: Yes. Run the **Tenda WiFi** App, tap **Settings** in the lower-right hand corner, tap **Add nova**, and follow the on-screen instructions to add nodes.

Q4: How to restore my network to factory settings?

A4: With your nodes powered on, hold the Reset (RST) button of your primary node down using a reset-pin or a paper clip for about 6 seconds. Release it when the LED indicator blinks fast. Your network is reset successfully when the LED indicator lights solid on and then blinks again. And all nodes are then restored to factory settings.

Q5: My 2.4 GHz WiFi-enabled devices, such as a home security camera, cannot connect to my nova WiFi network. What should I do?

A5: (1) Connect your smart phone used for setup to your nova WiFi network.

(2) Run the **Tenda WiFi** App, tap **Settings, Smart Assistant**, and **Enable**. Your smart phone connects to the 2.4 GHz WiFi network.

(3) Use the smart phone to set up your 2.4 GHz WiFi-enabled device guided by the App of the device you would like to connect.



CE Mark Warning

This is a Class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

Operations in the 5.15-5.25GHz band are restricted to indoor use only. This equipment should be installed and operated with a minimum distance 20cm between the device and your body.

NOTE: (1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.

WARNING: The mains plug is used as disconnect device; the disconnect device shall remain readily operable.

Declaration of Conformity

Hereby, Shenzhen Tenda Technology Co., Ltd. declares that the radio equipment type Mesh5 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:
<http://www.tendacn.com/en/service/download-cata-101.html>

Operating Frequency:

2.4 GHz: EU/2400-2483.5MHz (CH1-CH13)

5 GHz: EU/5150-5250MHz (CH36-CH48)

EIRP Power (Max.):

2.4 GHz: 19.26 dBm 5 GHz: 22.68 dBm Software Version: V1.0.0.X



FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device is for indoor usage only. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules.

This equipment should be installed and operated with a minimum distance 20cm between the device and your body.

Caution:

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. Operating frequency: 2412-2462MHz, 5150-5250MHz, 5725-5850MHz

NOTE:

(1) The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. (2) To avoid unnecessary radiation interference, it is recommended to use a shielded RJ45 cable.



Caution:

Adapter Model: BN036-A12012E/BN036-A12012B/BN036-A12012U

Manufacturer: SHENZHEN HEWEISHUN NETWORK

TECHNOLOGY CO., LTD.

Input: 100-240 V AC, 50/60 Hz, 0.4 A

Output: 12 V DC, 1 A

— : DC Voltage

Operating Environment

Temperature: 0°C-40°C Humidity: (10 - 90)% RH, non-condensing



RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys new electrical or electronic equipment.

For EU/EFTA, this product can be used in the following countries:

	BE	BG	CZ	DK	DE	EE	IE	EL	ES	FR	HR	IT	CY	LV
	LT	LU	HU	MT	NL	AT	PL	PT	RO	SI	SK	FI	SE	UK

Technical Support

Shenzhen Tenda Technology Co., Ltd.
6-8 Floor, Tower E3, No. 1001, Zhongshanyuan Road, Nanshan District, Shenzhen, China. 518052
USA hotline: 1-800-570-5892
Toll Free: 7 X 24 hours
Canada hotline: 1-888-998-8966
Toll Free: Mon-Fri 9 am - 6 pm PST
Hong Kong Hotline: 00852-81931998
Website: www.tendacn.com
Email: support.nova@tenda.com.cn

Copyright

© 2020 Shenzhen Tenda Technology Co., Ltd. All rights reserved. Tenda is a registered trademark legally held by Shenzhen Tenda Technology Co., Ltd. Other brand and product names mentioned herein are trademarks or registered trademarks of their respective holders. Specifications are subject to change without notice.



AC1200 Whole Home Mesh WiFi System
MW5c (2-pack)

Quick Installation Guide

